






**On the TiVo remote,
select TiVo button**

Press the left arrow 1 time and select OK







**Press the right arrow
2 times and highlight
the Help Tab**




Press down arrow to Restart Box and select OK





**Press Thumbs down
button 3 times and
then press enter
button**



**This should correct the
Voice button and the
network connection**